

Profils de l'écran tactile

What are touchscreen profiles?

For each touchscreen you can determine which actions are available and which buttons are shown on the touchscreen. To do so, you create [different touchscreen profiles](#). Thanks to these profiles, you can, for instance, select different actions on the ground floor than on the upper floor.

By default, one basic profile has been created. [Existing touchscreen profiles can be modified](#).